

APX™ TWO-WAY RADIOS

# APX 6000 MODEL 1

**INTERACTIVE END USER TOOLKIT (IEUTK)**



*Model 1*



1	<a href="#">FRONT COVER</a>
2	<a href="#">CONTENTS - 1/4</a>
3	<a href="#">CONTENTS - 2/4</a>
4	<a href="#">CONTENTS - 3/4</a>
5	<a href="#">CONTENTS - 4/4</a>
6	<a href="#">DECLARATION OF CONFORMITY</a>
7	<a href="#">DECLARATION OF CONFORMITY</a>
8	<a href="#">PRODUCT SAFETY AND RF EXPOSURE COMPLIANCE</a>
9	<a href="#">SOFTWARE VERSION</a>
10	<a href="#">COPYRIGHTS &amp; DISCLAIMER</a>
11	<a href="#">GETTING STARTED</a>
12	<a href="#">GETTING STARTED</a>
13	<a href="#">RADIO PARTS AND CONTROLS</a>
14	<a href="#">RADIO PARTS AND CONTROLS</a>
15	<a href="#">FLEET MAP</a>
16	<a href="#">PREPARING YOUR RADIO FOR USE - Charging the Battery</a>
17	<a href="#">PREPARING YOUR RADIO FOR USE - Attaching/Removing the Battery</a>
18	<a href="#">PREPARING YOUR RADIO FOR USE - Attaching/Removing the Antenna</a>
19	<a href="#">PREPARING YOUR RADIO FOR USE - Attaching/Removing the Accessory Connector Cover</a>
20	<a href="#">PREPARING YOUR RADIO FOR USE - Attaching the Belt Clip</a>

21	<a href="#">PREPARING YOUR RADIO FOR USE - Turning on/off the Radio</a>
22	<a href="#">PREPARING YOUR RADIO FOR USE - Adjusting the Volume</a>
23	<a href="#">IDENTIFYING RADIO CONTROLS - Programmable Features</a>
24	<a href="#">IDENTIFYING RADIO CONTROLS - Programmable Features</a>
25	<a href="#">IDENTIFYING RADIO CONTROLS - Programmable Features</a>
26	<a href="#">IDENTIFYING RADIO CONTROLS - Accessing the Preprogrammed Functions</a>
27	<a href="#">IDENTIFYING RADIO CONTROLS - Push-To-Talk (PTT) Button</a>
28	<a href="#">IDENTIFYING STATUS INDICATORS - Status Icons</a>
29	<a href="#">IDENTIFYING STATUS INDICATORS - Status Icons</a>
30	<a href="#">IDENTIFYING STATUS INDICATORS - LED Indicator</a>
31	<a href="#">IDENTIFYING STATUS INDICATORS - LED Indicator</a>
32	<a href="#">IDENTIFYING STATUS INDICATORS - Intelligent Lighting Indicators</a>
33	<a href="#">IDENTIFYING STATUS INDICATORS - Intelligent Lighting Indicators</a>
34	<a href="#">IDENTIFYING STATUS INDICATORS - Alert Tones</a>

35 [IDENTIFYING STATUS INDICATORS -  
Alert Tones](#)

36 [IDENTIFYING STATUS INDICATORS -  
Alert Tones](#)

37 [GENERAL RADIO OPERATION](#)

38 [GENERAL RADIO OPERATION -  
Selecting a Zone](#)

39 [GENERAL RADIO OPERATION -  
Selecting a Radio Channel](#)

40 [GENERAL RADIO OPERATION -  
Receiving and Responding to a Radio Call](#)

41 [GENERAL RADIO OPERATION -  
Receiving and Responding to a Radio Call - Receiving and  
Responding to a Talkgroup Call](#)

42 [GENERAL RADIO OPERATION -  
Receiving and Responding to a Radio Call - Receiving and  
Responding to a Private Call \(Trunking Only\)](#)

43 [GENERAL RADIO OPERATION -  
Receiving and Responding to a Radio Call - Receiving and  
Responding to a Telephone Call \(Trunking Only\)](#)

44 [GENERAL RADIO OPERATION -  
Making a Radio Call - Making a Talkgroup Call](#)

45 [GENERAL RADIO OPERATION -  
Repeater or Direct Operation](#)

46 [GENERAL RADIO OPERATION -  
Monitoring Features - Monitoring a Channel](#)

47 [GENERAL RADIO OPERATION -  
Monitoring Features - Conventional Mode Operation](#)

48 [ADVANCED FEATURES](#)

49 [ADVANCED FEATURES -  
Advanced Call Features - Receiving and Responding to a  
Selective Call \(Conventional Only\)](#)

50 [ADVANCED FEATURES -  
Advanced Call Features - Using the Dynamic Regrouping  
Feature \(Trunking Only\)](#)

51 [ADVANCED FEATURES -  
Advanced Call Features - Classifying Regrouped Radios](#)

52 [ADVANCED FEATURES -  
Advanced Call Features - Requesting a Reprogram \(Trunking  
Only\)](#)

53 [ADVANCED FEATURES -  
Scan Lists - Viewing a Scan List](#)

54 [ADVANCED FEATURES -  
Scan Lists - Changing the Priority Status](#)

55 [ADVANCED FEATURES -  
Scan - Turning Scan On or Off](#)

56 [ADVANCED FEATURES -  
Scan - Making a Dynamic Priority Change \(Conventional Scan  
Only\)](#)

57 [ADVANCED FEATURES -  
Scan - Deleting a Nuisance Channel](#)

58 [ADVANCED FEATURES -  
Scan - Restoring a Nuisance Channel](#)

59 [ADVANCED FEATURES -  
Call Alert Paging - Sending a Call Alert Page](#)

60 [ADVANCED FEATURES -  
Emergency Operation](#)

61	<a href="#"><u>ADVANCED FEATURES - Emergency Operation - Sending an Emergency Alarm</u></a>
62	<a href="#"><u>ADVANCED FEATURES - Emergency Operation - Sending an Emergency Call (Trunking Only)</u></a>
63	<a href="#"><u>ADVANCED FEATURES - Emergency Operation - Sending an Emergency Alarm with Emergency Call</u></a>
64	<a href="#"><u>ADVANCED FEATURES - Emergency Operation - Sending a Silent Emergency Alarm</u></a>
65	<a href="#"><u>ADVANCED FEATURES - Emergency Operation - Using the Emergency Keep-Alive Feature</u></a>
66	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
67	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
68	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
69	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
70	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
71	<a href="#"><u>ADVANCED FEATURES - Man Down</u></a>
72	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Selecting Secure/Clear Transmissions</u></a>
73	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Loading an Encryption Key</u></a>

74	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Using the Multikey Feature</u></a>
75	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Erasing the Selected Encryption Keys</u></a>
76	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Requesting an Over-the-Air Rekey (ASTRO Only)</u></a>
77	<a href="#"><u>ADVANCED FEATURES - Secure Operations - MDC Over-the-Air Rekeying (OTAR) Page</u></a>
78	<a href="#"><u>ADVANCED FEATURES - Secure Operations - Hear Clear</u></a>
79	<a href="#"><u>ADVANCED FEATURES - Trunking System Controls - Using the Fail-soft System</u></a>
80	<a href="#"><u>ADVANCED FEATURES - Trunking System Controls - Going Out of Range</u></a>
81	<a href="#"><u>ADVANCED FEATURES - Trunking System Controls - Using the Site Trunking Feature</u></a>
82	<a href="#"><u>ADVANCED FEATURES - Trunking System Controls - Locking and Unlocking a Site</u></a>
83	<a href="#"><u>ADVANCED FEATURES - Trunking System Controls - Viewing and Changing a Site</u></a>
84	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Turning the Bluetooth On/Off</u></a>
85	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Re-Pair Timer</u></a>
86	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Bluetooth Drop Timer</u></a>

87	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Pairing Bluetooth Device with the Radio</u></a>
88	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Pairing Bluetooth Device with the Radio</u></a>
89	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Indicating Bluetooth Connection is Lost</u></a>
90	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Turning On/Off the Bluetooth Audio</u></a>
91	<a href="#"><u>ADVANCED FEATURES - Mission Critical Wireless - Bluetooth - Clearing All Pairing Information</u></a>
92	<a href="#"><u>UTILITIES</u></a>
93	<a href="#"><u>UTILITIES - Using the Flip Display</u></a>
94	<a href="#"><u>UTILITIES - Selecting a Basic Zone Bank</u></a>
95	<a href="#"><u>UTILITIES - Selecting an Enhanced Zone Bank</u></a>
96	<a href="#"><u>UTILITIES - Selecting the Power Level</u></a>
97	<a href="#"><u>UTILITIES - Controlling the Display Backlight</u></a>
98	<a href="#"><u>UTILITIES - Locking and Unlocking the Controls</u></a>
99	<a href="#"><u>UTILITIES - Turning Voice Mute On or Off</u></a>
100	<a href="#"><u>UTILITIES - Using the Time-Out Timer</u></a>
101	<a href="#"><u>UTILITIES - Using the Conventional Squelch Operation Features</u></a>

102	<a href="#"><u>UTILITIES - Using the PL Defeat Feature</u></a>
103	<a href="#"><u>UTILITIES - Using the Digital PTT ID Feature</u></a>
104	<a href="#"><u>UTILITIES - Using the Smart PTT Feature (Conventional Only)</u></a>
105	<a href="#"><u>UTILITIES - Voice Announcement</u></a>
106	<a href="#"><u>UTILITIES - Voice Announcement</u></a>

This declaration is applicable to your radio only if your radio is labeled with the FCC logo shown below.

**DECLARATION OF CONFORMITY**

Per FCC CFR 47 Part 2 Section 2.1077(a)



Responsible Party

Name: Motorola Solutions, Inc.

Address: Motorola Solutions, Inc., 1303 East Algonquin Road Schaumburg, IL60196, U.S.A.

Phone Number: 1-800-927-2744

Hereby declares that the product:

Model Name: **APX 6000**

conforms to the following regulations:

FCC Part 15, subpart B, section 15.107(a), 15.107(d) and section 15.109(a)

**Class B Digital Device**

As a personal computer peripheral, this device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Caution

Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

## ATTENTION!

**This radio is restricted to occupational use only to satisfy FCC RF energy exposure requirements.**

Before using this product, read the RF energy awareness information and operating instructions in the Product Safety and RF Exposure booklet enclosed with your radio (Motorola Publication part number 6881095C99) to ensure compliance with RF energy exposure limits.

For a list of Motorola-approved antennas and other accessories, visit the following website: <http://www.motorola.com/APX>



All the features described in the following sections are supported by the radio's software version **R07.00.00** or later. See **Accessing Radio Information** to determine your radio's software version. Check with your dealer or system administrator for more details of all the features supported.

### Notice to Users (FCC and Industry Canada)

This device complies with Part 15 of the FCC rules and RSS 210 of the Industry Canada rules per the conditions listed below:

- 1 This device may not cause harmful interference.
- 2 This device must accept any interference received, including interference that may cause undesired operation.
- 3 Changes or modifications made to this device, not expressly approved by Motorola, could void the user's authority to operate this equipment.

**Computer Software Copyrights**

The Motorola products described in this manual may include copyrighted Motorola computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted computer programs including, but not limited to, the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Motorola computer programs contained in the Motorola products described in this manual may not be copied, reproduced, modified, reverse-engineered, or distributed in any manner without the express written permission of Motorola. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppels, or otherwise, any license under the copyrights, patents or patent applications of Motorola, except for the normal non-exclusive license to use that arises by operation of law in the sale of a product.

**Documentation Copyrights**

No duplication or distribution of this document or any portion thereof shall take place without the express written permission of Motorola. No part of this manual may be reproduced, distributed, or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of Motorola.

**Disclaimer**

The information in this document is carefully examined, and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Motorola reserves the right to make changes to any products herein to improve readability, function, or design. Motorola does not assume any liability arising out of the applications or use of any product or circuit described herein; nor does it cover any license under its patent rights, nor the rights of others.

This Interactive End User Toolkit (IEUTK) covers the basic operation of the APX 6000 Model 1.

However, your dealer or system administrator may have customized your radio for your specific needs. Check with your dealer or system administrator for more information.

Adobe Flash player is required to run the demos included with this kit.

Please refer to the Adobe website (<http://get.adobe.com/flashplayer/>) to update/download/install the Adobe Flash Player.

### **Notations Used in This Tutorial**

Throughout the text in this toolkit, you will notice the use of **WARNING**, **Caution**, and **Note**. These notations are used to emphasize that safety hazards exist, and the care that must be taken or observed.



An operational procedure, practice, or condition, etc., which may result in injury or death if not carefully observed.



An operational procedure, practice, or condition, etc., which may result in damage to the equipment if not carefully observed.

**Note:** *An operational procedure, practice, or condition, etc., which is essential to emphasize.*

The following special notations identify certain items:

Example	Description
<a href="#">DEMO</a>	Click to play demo of the procedure.

### **Additional Performance Enhancement**

The following are some of the latest creations designed to enhance the security, quality and efficiency of APX radios.

#### **Dynamic System Resilience (DSR)**

DSR ensures the radio system is seamlessly switched to a backup master site dynamically in case of system failure. DSR also provides additional indication e.g. failure detection, fault recovery, and redundancy within the system to address to the user in need. Mechanisms related to the Integrated Voice and Data (IV & D) or data centric are all supported by DSR.

#### **CrossTalk Prevention**

This feature prevents crosstalk scenario from happening, especially when a wideband antenna is used. This feature allows the adjustment of the Trident Transmitting SSI clock rate in the radio to be varied from the Receiving Frequency. This subsequently reduced the possibilities of radio frequency interfering spurs and prevents the issues of crosstalk.

#### **Encrypted Integrated Data (EID)**


EID provides security encryption and authentication of IV & D data bearer service communication between the radio and the Customer Enterprise Network.

#### **SecureNet**

SecureNet allows user to perform secured communications on an Analog or Motorola Data Communication (MDC) channel. The MDC OTAR feature will allow users to perform OTAR activities on an MDC channel.



**\* These radio controls/buttons are programmable.**



**\* These radio controls/buttons are programmable.**

	Z1	Z2	Z3	Z4	Z5	Z6
C1						
C2						
C3						
C4						
C5						
C6						
C7						
C8						
C9						
C10						
C11						
C12						
C13						
C14						
C15						
C16						

## ❑ Charging the Battery

**To avoid a possible explosion:**

- **DO NOT** replace the battery in any area labeled “hazardous atmosphere”.
- **DO NOT** discard batteries in a fire.

The Motorola-approved battery shipped with your radio is uncharged. Prior to using a new battery, charge it for a minimum of 16 hours to ensure optimum capacity and performance.

**Note:** When charging a battery attached to a radio, turn the radio off to ensure a full charge.

### Battery Charger

To charge the battery, place the battery, with or without the radio, in a Motorola-approved charger. The charger’s LED indicates the charging progress; see your charger’s user guide.



## ❑ Attaching/Removing the Battery

With the radio turned off, slide the battery into the radio's frame until side latches click into place.

To remove the battery, turn the radio off. Squeeze the release latches at the bottom of the battery until the battery releases from the radio. Remove the battery from the radio.

**Note:** If your radio is preprogrammed with volatile-key retention, the encryption keys are retained for approximately 30 seconds after battery removal.

Check with your dealer or system administrator for more information.



## ❑ Attaching/Removing the Antenna

With the radio turned off, set the antenna in its receptacle and turn clockwise to attach it to the radio.

To remove the antenna, turn the antenna counterclockwise.  
Make sure you turn off the radio first.



## ❑ Attaching/Removing the Accessory Connector Cover

The accessory connector is located on the antenna side of the radio. It is used to connect accessories to the radio.

**Note:** To prevent damage to the connector, shield it with the connector cover when not in use. Accessory Connector Cover must be fully secured to meet the salt water submersion specification.



Slide the Accessory Connector Cover over the antenna and position at the base of the antenna.

Insert the hooked end of the cover into the slot above the connector.

Press downward on the cover's top to seat it in the slot.

Once in place, tighten by rotating the thumbscrew clockwise by hand.


To remove the accessory connector cover, rotate the thumbscrew counterclockwise until it disengages from the radio.

If the thumbscrew is too tight, use an Allen wrench to loosen it first.


Rotate and lift the connector cover to disengage it from the radio.

## ❑ Attaching the Belt Clip

Align the grooves of the belt clip with those of the radio and press upward until you hear a click.



To remove the radio from the carry holder, place the tip of your fingers on the ledge of the carry holder and push at the bottom of the radio until the radio is released from it.





## ❑ Turning on/off the Radio

Rotate the **On/Off/Volume Control Knob** clockwise until you hear a click.


If the power-up test is successful, you see **SELFTEST** on the radio's display momentarily, followed by the Home screen.

**Note:** If the power-up test is unsuccessful, you see **Error XX/YY** (XX/YY is an alphanumeric code). Turn off the radio, check the battery, and turn the radio back on. If the radio fails the power-up test again, record the **Error XX/YY** code and contact your dealer.

**Note:** If the power-up test is successful, but you see **Hardware board absent** or **Hw Board Mismatch**. Then, send the radio to the qualified technician to fix this error.

If the power-up test is successful, but you see, **Hw Board Failed** or **Man-Down Hw Error**, send the radio to the qualified technician to fix this error.

To turn off your radio, rotate the **On/Off/Volume Control Knob** counterclockwise until you hear a click.




## ❑ Adjusting the Volume

To increase the volume, turn the **On/Off/Volume Control Knob** clockwise.

To decrease the volume, turn this knob counterclockwise.

**Note:** Ensure that the main speaker is pointed towards you for increased loudness and intelligibility, especially in areas with loud background noises.



## ❑ Programmable Features

Any reference in this manual to a control that is “preprogrammed” means that the control must be programmed by a dealer or a qualified radio technician using the radio’s programming software, in order to assign a feature to that control.

The programmable buttons can be programmed as shortcuts to radio functions or preset channels/groups depending on the duration of a button press:

- **Press** – Pressing and releasing rapidly.
- **Long press** – Pressing and holding for the programmed duration (between 0.25 seconds and 3.75 seconds).
- **Hold down** – Keeping the button pressed.

### Assignable Radio Functions

**Bluetooth On/Off** – Allows you to turn on/off the Bluetooth.

**Bluetooth Configuration** – Allows you to access to the Bluetooth menu.

**Bluetooth Audio Reroute** – Allows you to toggle the audio route between radio speaker or Remote Speaker Microphone and Bluetooth headset.

**Bluetooth Headset PTT** – Keys up the Bluetooth Headset's microphone.

**Bluetooth Clear All Pairing** – Allows you to clear all pairing info for Bluetooth. This is accessed by a long press of the Bluetooth On/Off Button.

**Call Response** – Allows you to answer a private call.

**Dynamic Priority (Conventional Only)** – Allows any channel in a scan list (except for the Priority-One channel) to temporarily replace the Priority-Two channel.

**Emergency** – Depending on the programming, initiates or cancels an emergency alarm or call.

**Internet Protocol Address** – Displays the Internet Protocol (IP) address, device name and status of the radio.

**Man Down Clear** – Clears the alarm of Man Down mode which was triggered when your radio achieves or passes a tilt angle threshold or a combination of the angle threshold and a motion sensitivity level.

**Monitor (Conventional Only)** – Monitors a selected channel for all radio traffic until function is disabled.

**Nuisance Delete** – Temporarily removes an unwanted channel, except for priority channels or the designated transmit channel, from the scan list.

**One Touch 1 – 4** – Launches a specific feature with one single button-press. You can setup as many as four separately programmed buttons for four different features.

**Private Line Defeat (Conventional Only)** – Overrides any coded squelch (DPL or PL) that is preprogrammed to a channel.

**Rekey Request** – Notifies the dispatcher you want a new encryption keys.

**Repeater Access Button (RAB) (Conventional Only)** – Allows to manually send a repeater access codeword.

**Reprogram Request (Trunking Only)** – Notifies the dispatcher you want a new dynamic regrouping assignment.

**Request-To-Talk (Conventional Only)** – Notifies the dispatcher you want to send a voice call.

**Scan** – Toggles scan on or off.

**Scan List Programming** – Selects the scan list for editing (by long press on the Scan button).

**Secure Transmission Select (Conventional and Trunking)** – Toggles the Secure Transmission On or Off when the Secure/Clear Strapping fields is set to “Select” for the radio’s current channel, and when the radio is model/option capable.

**Site Display/Search (Trunking Only)** – Displays the current site ID and RSSI value; performs site search for AMSS (Automatic Multiple Site Select) or SmartZone operation.

**Site Lock/Unlock (Trunking Only)** – Locks onto a specific site.

**Talkaround/Direct (Conventional Only)** – Toggles between using a repeater and communicating directly with another radio.

**Text Messaging Service (TMS)** – Selects the text messaging menu.



**Basic Zone Bank** – Provides access from up to 6 zones by toggling between 2 banks of 3 zones, one group of 3 (A, B and C) to a second group of 3 zones (D, E and F).

**Enhanced Zone Bank** – Provides access from up to 75 zones by toggling between 25 banks (A, B ... X or Y) of 3 zones.

### Assignable Settings or Utility Functions

**Controls Lock** – Locks or unlocks the programmable buttons, switches and rotary knobs.

**Light/Flip** – Press the button to toggle the display backlight on or off; press and hold the button to reverse the content of the top display.

**TX Power Level** – Toggles transmit power level between high and low.

**Voice Announcement** – Audibly indicates the current feature mode, Zone or Channel the user has just assigned.

**Voice Mute** – Toggles voice mute on or off.

**Volume Set Tone** – Sets the volume set tone.

## ❑ Accessing the Preprogrammed Functions

You can access various radio functions through a short or long press of the relevant programmable buttons.



## ❑ Push-To-Talk (PTT) Button

The **PTT** button on the side of the radio serves two basic purposes:

- While a call is in progress, the **PTT** button allows the radio to transmit to other radios in the call. Press and hold down **PTT** button to talk. Release the **PTT** button to listen. The microphone is activated when the **PTT** button is pressed.
- While a call is not in progress, the **PTT** button is used to make a new call.

Push-to-Talk  
(PTT) Button



## ❑ Status Icons

The 130 x 130 pixel front liquid crystal display (LCD) of your radio shows radio status, text entries, and menu entries. The top two display rows contain color icons that indicate radio operating conditions.

The following are the icons that appear on the radio's display.



### Battery

For IMPRES battery operation only – the icon shown indicates the charge remaining in the battery.  
For all battery operation – the icon blinks when the battery is low.



### Received Signal Strength Indicator (RSSI)

The number of bars displayed represents the received signal strength for the current site, for trunking only. The more stripes in the icon, the stronger the signal.




### Direct

- On = Radio is currently configured for direct radio-to-radio communication (during conventional operation only).
- Off = Radio is connected with other radios through a repeater.



### Monitor (Carrier Squelch)

Selected channel is being monitored (during conventional operation only).



### Power Level

- L = Radio is set at Low power.
- H = Radio is set at High power.



### Scan

Radio is scanning a scan list.




### Priority Channel Scan

- Blinking dot = Radio detects activity on channel designated as Priority-One.
- Steady dot = Radio detects activity on channel designated as Priority-Two.




### Vote Scan Enabled

The vote scan feature is enabled.



### Basic Zone Bank 1

- A = Radio is in Zone 1.
- B = Radio is in Zone 2.
- C = Radio is in Zone 3.



### Basic Zone Bank 2

- D = Radio is in Zone 4.
- E = Radio is in Zone 5.
- F = Radio is in Zone 6.

**Enhanced Zone Bank**

A = Contains Zone 1, Zone 2 and Zone 3,

B = Contains Zone 4, Zone 5 and Zone 6,

C = Contains Zone 7, Zone 8 and Zone 9,



X = Contains Zone 70, Zone 71 and Zone 72,

Y = Contains Zone 73, Zone 74 and Zone 75.

**Secure Operation**

- On = Secure operation.
- Off = Clear operation.
- Blinking = Receiving an encrypted voice call.

**Bluetooth On**

Bluetooth is on and ready for Bluetooth connection.

**Bluetooth Connected**

Bluetooth is currently connected to the external Bluetooth device.

## ❑ LED Indicator

The LED indicator shows the operational status of your radio.



**Solid red** – Radio is transmitting.

**Blinking red** – Radio is transmitting at low battery condition.

**Rapidly blinking red** – Radio has failed the self test upon powering up or encountered a fatal error.

**Solid yellow (Conventional Only)** – Channel is busy.

**Blinking yellow** – Radio is receiving a secured transmission.

**Solid green** – Radio is powering up, or is on a non-priority channel while in the Scan List Programming mode.

**Blinking green** – Radio is receiving an individual or telephone call, or is on a Priority-Two channel while in the Scan List Programming mode.

**Rapidly blinking green** – Radio is on a Priority-One channel while in the Scan List Programming mode.

**Note:** No LED indication when the radio receives a clear (non-secured) transmission in trunking Mode.


## ❑ Intelligent Lighting Indicators

This feature temporarily changes the radio's display backlight color and the alert text background color to help signal that a radio event has occurred.

**Note:** This feature must be preprogrammed by a qualified radio technician.

Backlight and Bar Color	Notification	When
Orange	Emergency Alerts	The radio initiates an emergency alarm or call.
		The radio receives an emergency alarm or call.
		The radio initiates the Man Down Post-Alert timer.
Red	Critical Alerts	The radio battery is low.
		The radio is out of range.
		The radio enters fail-soft mode.
		The radio is unable to establish a full connection with the system.
		The radio is unable to authenticate or register with the system.
Green	Call Alerts	The radio receives a private call.
		The radio receives a phone call.
		The radio receives a call alert.
		The radio receives a selective call.





**Orange**  
Emergency Alerts






**Red**  
Critical Alerts







**Green**  
Call Alerts

## ❏ Alert Tones

An alert tone is a sound or group of sounds. Your radio uses alert tones to inform you of your radio's conditions. The following table lists these tones and when they occur.

You Hear	Tone Name	Heard
<b>Short, Low-Pitched Tone</b>   <b>Play</b>	Radio Self Test Fail	When radio fails its power-up self test.
	Reject	When unauthorized request is made.
	Time-Out Timer Warning	Four seconds before time out.
	No ACK Received	When radio fails to receive an acknowledgment.
	Individual Call Warning Tone	When radio is in an individual call for greater than 6 seconds without any activity.
<b>Long, Low-Pitched Tone</b>   <b>Play</b>	Time-Out Timer Timed Out	After time out.
	Talk Prohibit/ <b>PTT</b> Inhibit	(When <b>PTT</b> button is pressed) transmissions are not allowed.
	Out of Range	(When <b>PTT</b> button is pressed) the radio is out of range of the system.
	Invalid Mode	When radio is on an unpreprogrammed channel.
<b>A Group of Low-Pitched Tones</b>   <b>Play</b>	Busy	When system is busy.

You Hear	Tone Name	Heard
<b>Short, Medium-Pitched Tone</b>   <b>Play</b>	Valid Key-Press	When correct key is pressed.
	Radio Self Test Pass	When radio passes its power-up self test.
	Clear Voice	At beginning of a non-coded communication.
	Priority Channel Received	When activity on a priority channel is received.
	Emergency Alarm Entry	When entering the emergency state.
	Central Echo	When central controller has received a request from a radio.
<b>Long, Medium-Pitched Tone</b>   <b>Play</b>	Volume Set	When volume is changed on a quiet channel.
	Emergency Exit	When exiting the emergency state.
<b>A Group of Medium-Pitched Tones</b>   <b>Play</b>	Fail-soft	When the trunking system fails.
	Automatic Call Back	When voice channel is available from previous request.
	Talk Permit	(When <b>PTT</b> button is pressed) verifying system accepting transmissions.
	Keyfail	When encryption key has been lost.
	Console Acknowledge	When status, emergency alarm, or reprogram request ACK is received.
	Received Individual Call	When Call Alert or Private Call is received.
	Site Trunking	When a SmartZone trunking system fails.
<b>Short, High-Pitched Tone (Chirp)</b>	Low-Battery Chirp	When battery is below preset threshold value.

You Hear	Tone Name	Heard
<b>Ringing</b>	Fast Ringing	When system is searching for target of Private Call.
	Enhanced Call Sent	When waiting for target of Private Call to answer the call.
	Phone Call Received	When a land-to-mobile phone call is received.
<b>Gurgle</b>  <b>Play</b>	Dynamic Regrouping	(When the <b>PTT</b> button is pressed) a dynamic ID has been received.
<b>Unique, Low-Pitched Chirp</b>	New Message	When a new message is received.
<b>Unique, High-Pitched Chirp</b>	Priority Status	When a priority message is received.
<b>Incremental-Pitched Tone</b>	Bluetooth Paired Tone	When Bluetooth accessory is paired with the radio.
	Bluetooth Connected Tone	When Bluetooth accessory is connected to the radio.
<b>Decremental-Pitched Tone</b>	Bluetooth Unpaired Tone	When Bluetooth accessory is unpaired from the radio.
	Bluetooth Disconnected Tone	When Bluetooth accessory is disconnected from the radio.
<b>A Group of Very High-Pitched Tones</b>	Man Down Continuous Tone	When radio is in Man Down mode and prepares to transmit Emergency Alarm when the timer of this alarm ends.
<b>Doh-Sol</b>	Enhanced Zone Bank Up	When <b>EZB Up</b> button is pressed to scroll the Enhance Zone Bank up.
<b>Sol-Doh</b>	Enhanced Zone Bank Dow	When <b>EZB Down</b> button is pressed to scroll the Enhance Zone Bank down.

<b><u>Selecting a Zone .....</u></b>	<b>38</b>
<b><u>Selecting a Radio Channel .....</u></b>	<b>39</b>
<b><u>Receiving and Responding to a Radio Call .....</u></b>	<b>40</b>
<i>Receiving and Responding to a Talkgroup Call .....</i>	<i>41</i>
<i>Receiving and Responding to a Private Call (Trunking Only)</i>	<i>42</i>
.....	
<i>Receiving and Responding to a Telephone Call (Trunking Only).....</i>	<i>43</i>
<b><u>Making a Radio Call .....</u></b>	<b>44</b>
<i>Making a Talkgroup Call .....</i>	<i>44</i>
<b><u>Repeater or Direct Operation .....</u></b>	<b>45</b>
<b><u>Monitoring Features .....</u></b>	<b>46</b>
<i>Monitoring a Channel .....</i>	<i>46</i>
<i>Conventional Mode Operation .....</i>	<i>47</i>


## ❑ Selecting a Zone

A zone is a group of channels.

### Procedure:

DEMO

- 1 Move the preprogrammed **Zone (3-Position A/B/C)** switch to the position of the required zone
- 2 Press the **PTT** button to transmit on the displayed zone channel.




## ❑ Selecting a Radio Channel

A channel is a group of radio characteristics, such as transmit/receive frequency pairs.

### Procedure:

**DEMO**

- 1 Turn the preprogrammed **16-Position Select Knob** to the desired channel.
- 2 Press the **PTT** button to transmit on the displayed zone channel.



## ❑ Receiving and Responding to a Radio Call

Once you have selected the required channel and/or zone, you can proceed to receive and respond to calls.

The LED lights up solid red while the radio is transmitting. In conventional mode, the LED lights up solid yellow when the radio is receiving a transmission. In trunking mode, there is no LED indication when the radio receives a transmission.

If the radio is receiving a secure transmission, the LED blinks yellow.





## ❑ Receiving and Responding to a Radio Call

### *Receiving and Responding to a Talkgroup Call*

To receive a call from a group of users, your radio must be configured as part of that talkgroup.

#### Procedure:

When you receive a talkgroup call (while on the Home screen), depending on how your radio is preprogrammed:

**1 ASTRO Conventional Only:**

The LED lights up solid yellow.

**OR**


**Trunking Only:**

The display shows the caller alias or ID.

**2 Press the **PTT** button to respond to the call.**

The LED lights up solid red.

**3 Release the **PTT** button to listen.**



## ❑ Receiving and Responding to a Radio Call

### *Receiving and Responding to a Private Call (Trunking Only)*

A Private Call is a call from an individual radio to another individual radio.

These one-to-one calls between two radios are not heard by others in the current talkgroup. The calling radio automatically verifies that the receiving radio is active on the system and can display the caller ID.

**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.


#### Procedure:

When you receive a Private Call:

- 1 You hear two alert tones and the LED blinks green. The display shows **CALL RCV**, alternating with the caller alias (name) or ID (number). Press the **Call Response** button within 20 seconds after the call indicators begin.

- 2 Press and hold the **PTT** button to talk. Release the **PTT** button to listen.
- 3 Press **Call Response** button to hang up and return to the Home screen.

You cannot initiate a Private Call.



## ❑ Receiving and Responding to a Radio Call

### *Receiving and Responding to a Telephone Call (Trunking Only)*

This feature allows you to receive calls similar to standard phone calls from a landline phone.


**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

#### Procedure:

Use the preprogrammed **Call Response** button to answer a **Telephone Call**:

- 1 You hear a telephone-type ringing and the LED blinks green.  
The backlight of the screen turns green.  
The display shows **PHN CALL**.  
Press the **Call Response** button within 20 seconds after the call indicators begin.
- 2 Press and hold the **PTT** button to talk.  
Release the **PTT** button to listen.

- 3 Press **Call Response** button to hang up and return to the Home screen.



## ❑ Making a Radio Call

### *Making a Talkgroup Call*

You can select a zone, channel, subscriber ID, or talkgroup by using:

- The preprogrammed Zone switch
- A preprogrammed **One Touch Call** button

To make a call to a group of users, your radio must be configured as part of that talkgroup.

#### Procedure:

**DEMO**

- 1 Turn the **16-Position Select Channel Knob** to select the channel with the desired talkgroup.

- 2 Press the **PTT** button to make the call.

#### **ASTRO Conventional Only:**

The LED lights up solid red.

The display shows the talkgroup alias or ID.


#### **OR**

#### **Trunking Only:**

The LED lights up solid red.

Speak clearly into the microphone.

Release the **PTT** button to listen.



## ❑ Repeater or Direct Operation

The **REPEATER** operation increases the radio's range by connecting with other radios through a repeater. The transmit and receive frequencies are different.

The **DIRECT** or "talkaround operation" allows you to bypass the repeater and connect directly to another radio. The transmit and receive frequencies are the same.


### Procedure:

- 1 Press the preprogrammed **Repeater/Direct** switch to toggle between talkaround and repeater modes.

The display shows **RPTR MODE** if the radio is currently in Repeater mode.

**OR**

The display shows **DIR MODE** and the Talkaround icon if the radio is currently in Direct mode (during conventional operation only).



## ❏ Monitoring Features

### *Monitoring a Channel*

Radio users who switch from analog to digital radios often assume that the lack of static on a digital channel is an indication that the radio is not working properly. This is not the case.

Digital technology quiets the transmission by removing the “noise” from the signal and allowing only the clear voice or data information to be heard.

Monitor a channel to ensure the channel is clear before transmitting.

#### **Procedure:**

- 1 Press the preprogrammed **Monitor** button.
- 2 Adjust the **Volume Control Knob** if necessary.
- 3 Press and hold the **PTT** button to transmit.  
The LED lights up solid red.  
Release the **PTT** button to receive (listen).

The Carrier Squelch indicator appears on the display when you monitor a channel via the preprogrammed **Monitor** button.

## ❑ Monitoring Features

### *Conventional Mode Operation*

Your radio may be preprogrammed to receive Private-Line® (PL) calls.

#### Procedure:

- 1 Momentarily press the **Monitor** button to listen for activity. The Carrier Squelch indicator appears on the display.
- 2 Press and hold the **Monitor** button to set continuous monitor operation. The duration of the button press is programmable.
- 3 Press the **Monitor** button again, or the **PTT** button, to return to the original squelch setting.

If you try to transmit on a receive-only channel, you hear an invalid tone until you release the **PTT button**.





<b><u>Advanced Call Features .....</u></b>	<b>49</b>
Receiving and Responding a Selective Call (Conventional Only).....	49
Using the Dynamic Regrouping Feature (Trunking Only).....	50
Classifying Regrouped Radios.....	51
Requesting a Reprogram (Trunking Only) .....	52
<b><u>Scan Lists.....</u></b>	<b>53</b>
Viewing a Scan List .....	53
Changing the Priority Status.....	54
<b><u>Scan .....</u></b>	<b>55</b>
Turning Scan On or Off.....	55
Making a Dynamic Priority Change (Conventional Scan Only) .....	56
Deleting a Nuisance Channel .....	57
Restoring a Nuisance Channel .....	58
<b><u>Call Alert Paging .....</u></b>	<b>59</b>
Sending a Call Alert Page .....	59
<b><u>Emergency Operation .....</u></b>	<b>60</b>
Sending an Emergency Alarm .....	61
Sending an Emergency Call (Trunking Only) .....	62
Sending an Emergency Alarm with Emergency Call .....	63
Sending a Silent Emergency Alarm .....	64
Using the Emergency Keep-Alive Feature .....	65
<b><u>Man Down .....</u></b>	<b>66</b>

<b><u>Secure Operations .....</u></b>	<b>72</b>
Selecting Secure/Clear Transmissions .....	72
Loading an Encryption Key .....	73
Using the Multikey Feature .....	74
Erasing the Selected Encryption Keys .....	75
Requesting an Over-the-Air Rekey (ASTRO Conventional Only) .....	76
MDC Over-the-Air Rekeying (OTAR) Page .....	77
Hear Clear .....	78
<b><u>Trunking System Controls .....</u></b>	<b>79</b>
Using the Fail-soft System .....	79
Going Out of Range .....	80
Using the Site Trunking Feature .....	81
Locking and Unlocking a Site .....	82
Viewing and Changing a Site .....	83
<b><u>Mission Critical Wireless - Bluetooth - .....</u></b>	<b>84</b>
Turning the Bluetooth On/Off .....	84
Re-Pair Timer .....	85
Bluetooth Drop Timer .....	86
Pairing Bluetooth Device with the Radio .....	87
Indicating Bluetooth Connection is Lost .....	89
Turning On/Off the Bluetooth Audio .....	90
Clearing All Pairing Information .....	91



## ❑ Advanced Call Features

### *Receiving and Responding to a Selective Call (Conventional Only)*

This feature allows you to receive a call from or to call a specific individual. It is intended to provide privacy and to eliminate the annoyance of having to listen to conversations that are of no interest to you.

#### Receiving a Selective Call

##### **Procedure:**

When you receive a Selective Call:

- 1 You hear two alert tones and the LED lights up solid yellow. The call received icons blinks and the display shows **CALL RCV**.


You hear two alert tones, the LED lights up solid yellow to indicate the transmitting radio is still sending signal.

The speaker unmutes.

Press and hold the **PTT** button to talk.

Release the **PTT** button to listen.

You cannot initiate a Selective Call.



## ❑ Advanced Call Features

### *Using the Dynamic Regrouping Feature (Trunking Only)*

This feature allows the dispatcher to temporarily reassign selected radios to a particular channel where they can communicate with each other. This feature is typically used during special operations and is enabled by a qualified radio technician.

You will not notice whether your radio has this feature enabled until a dynamic regrouping command is sent by the dispatcher.

**Note:** If you try to access a zone or channel that has been reserved by the dispatcher as a dynamically regrouped mode for other users, you hear an invalid tone.

#### **Procedure:**

- 1 When your radio is dynamically regrouped, it automatically switches to the dynamically regrouped channel. You hear a “gurgle” tone and the display shows the dynamically regrouped channel’s name.  
Press the **PTT** button to talk.  
Release the **PTT** button to listen.

When the dispatcher cancels dynamic regrouping, the radio automatically returns to the zone and channel that you were using before the radio was dynamically regrouped.

## ❑ Advanced Call Features

### *Classifying Regrouped Radios*

The dispatcher can classify regrouped radios into either of two categories: **Select Enabled** or **Select Disabled**.

- Select-enabled radios are free to change to any available channel, including the dynamic-regrouping channel, once the user has selected the dynamic-regrouping position.
- Select-disabled radios cannot change channels while dynamically regrouped. The dispatcher has forced the radio to remain on the dynamic-regrouping channel.

The Scan or Private Call feature cannot be selected while your radio is Select Disabled.




## ❑ Advanced Call Features

### *Requesting a Reprogram (Trunking Only)*

This feature allows you to notify the dispatcher when you want a new dynamic regrouping assignment.

#### Procedure:

- 1 Press the preprogrammed **Reprogram Request** button to send reprogram request to the dispatcher. The display shows **Reprgrm rqst** and **Please wait**. If you hear five beeps, the dispatcher has acknowledged the reprogram request. The display shows **ACK RCVD** and the radio returns to the Home screen.
- OR**
- If the dispatcher does not acknowledge the reprogram request within six seconds, you hear a low-pitched alert tone and the display shows **NO ACK**. The radio returns to the Home screen.



## ❑ Scan Lists

### *Viewing a Scan List*

Scan lists are created and assigned to individual channels/groups.

Your radio scans for voice activity by cycling through the channel/group sequence specified in the scan list for the current channel/group.

Your radio supports different types of Scan Lists:


- Trunking Priority Monitor Scan List
- Conventional Scan List
- Talkgroup Scan List

Please refer to a qualified radio technician for the maximum number of Scan Lists can be programmed in your radio.

These lists must be preprogrammed by a qualified radio technician.

#### Procedure:

- 1 Turn the **16-Position Select knob** to view the members on the list.



## ❏ Scan Lists

### *Changing the Priority Status*

#### Procedure:

- 1 Press the **Top Side (Select)** button to change the priority status of the currently displayed channel or the scan list status icon of the currently displayed channel.

#### Priority Status

A Scan icon indicates that the current channel is in the scan list as a non-priority channel.

The LED lights up solid green.

#### **OR**

A Priority-Two Channel Scan icon indicates that the current channel is in the scan list as the Priority-Two channel.

The LED blinks green.

#### **OR**

A Priority-One Channel Scan icon indicates that the current channel is in the scan list as the Priority-One channel.

The LED rapidly blinks green.

You hear all traffic on the Priority-One channel, regardless of traffic on non-priority channels.

#### **OR**

No icon indicates that the current channel is deleted from the scan list.

## ❑ Scan

### *Turning Scan On or Off*

This feature allows you to monitor traffic on different channels by scanning a preprogrammed list of channels.


#### Procedure:

- 1 Press the preprogrammed **Scan** button, or turn the preprogrammed Scan switch to the Scan on or Scan off position, to initiate or stop scan.

The display shows **SCAN ON** and the scan icon, indicating that scan is enabled.

#### OR

The display shows **SCAN OFF** and the scan icon, indicating that scan is enabled.



## ❑ Scan

### *Making a Dynamic Priority Change (Conventional Scan Only)*


While the radio is scanning, the dynamic priority change feature allows you to temporarily change any channel in a scan list (except for the Priority-One channel) to the Priority-Two channel.

This change remains in effect until scan is turned off. Scan then reverts to the preprogrammed (original) setting.

#### Procedure:

- 1 When the radio locks onto the channel designated as the new Priority-Two channel, press the preprogrammed **Dynamic Priority** button.

The radio continues scanning the remaining channels in the list.





## ❏ Scan

### *Deleting a Nuisance Channel*

If a channel continually generates unwanted calls or noise (termed a “nuisance” channel), you can temporarily remove the unwanted channel from the scan list.

This capability does not apply to priority channels or the designated transmit channel.

#### Procedure:

- 1 When the radio is locked onto the channel to be deleted, press the preprogrammed **Nuisance Delete** button. The radio continues scanning the remaining channels in the list.




## ☐ Scan

### *Restoring a Nuisance Channel*

#### Procedure:

To restore the deleted nuisance channel, do one of the following:

- Turn the radio off and then turning it on again.  
**OR**
- Stop and restart a scan via the preprogrammed **Scan** button.  
**OR**
- Change the channel via the **16-Position Select knob**.



## ☐ Call Alert Paging

### *Sending a Call Alert Page*

This feature allows your radio to work like a pager.

**Note:** This feature must be preprogrammed by a qualified radio technician.

When you receive a Call Alert page, you hear four repeating alert tones and the LED blinks green. The call received icon blinks and the display shows **PAGE RCV**.

You cannot send a Call Alert page.

## ❑ Emergency Operation

The Emergency feature is used to indicate a critical situation.

If the **Top (Orange)** button is preprogrammed to send an emergency signal, this signal overrides any other communication over the selected channel.

Your radio supports the following Emergency modes:


- Emergency Alarm
- Emergency Call (Trunking Only)
- Emergency Alarm with Emergency Call
- Silent Emergency Alarm

Check with your dealer or system administrator for more information on the programming of this feature.

Only **one** of the Emergency modes above can be assigned to the preprogrammed **Emergency** button.

**Note:** To exit emergency at any time, press and hold the preprogrammed **Emergency** button for about a second.

Man Down is an alternate way to activate the Emergency feature on the condition the Emergency must be set up for this feature to operate.



## ❑ Emergency Operation

### *Sending an Emergency Alarm*

This feature allows you to send a data transmission, which identifies the radio sending the emergency, to the dispatcher.

**Note:** Emergency button press timer by default is set to 1 second. This timer is programmable from 0 – 6 seconds by a qualified technician.

#### Procedure:

**DEMO**

- 1 Press the preprogrammed **Emergency** button.

The display shows **EMERGENCY** and the current zone or channel.

You hear a short, medium-pitched tone and the LED momentarily blinks red.

#### OR

You hear the radio sounds a short low-pitched tone to indicate the selected channel does not support emergency and rejects to launch emergency mode.


When you receive the dispatcher's acknowledgment, the display shows **ACK RCVD**.

You hear four tones, the alarm ends, and the radio exits the Emergency Alarm mode.

#### OR

If no acknowledgement is received, the display shows **NO ACK**.

The alarm ends and the radio exits the Emergency Alarm mode.



## ❑ Emergency Operation

### *Sending an Emergency Call (Trunking Only)*

This feature gives your radio priority access on a channel.

**Note:** The radio operates in the normal dispatch manner while in Emergency Call, except, if enabled, it returns to one of the following:

- **Tactical/Non-Revert** – You talk on the channel you selected before you entered the emergency state.
- **Non-Tactical/Revert** – You talk on a preprogrammed emergency channel. The emergency alarm is sent on this same channel.

#### Procedure:

**DEMO**

- 1 Press the preprogrammed **Emergency** button.


The display shows **EMERGENCY** and the current zone or channel.

You hear a short, medium-pitched tone and the LED momentarily blinks red.

#### OR

You hear the radio sounds a short low-pitched tone to indicate the selected channel does not support emergency and rejects to launch emergency mode.

- 2 Press and hold the **PTT** button.  
Speak clearly into the microphone.
- 3 Release the **PTT** button to end the transmission and wait for a response from the dispatcher.
- 4 Press and hold the preprogrammed **Emergency** button for about a second to exit the Emergency Call mode.



## ❑ Emergency Operation

### *Sending an Emergency Alarm with Emergency Call*

#### Procedure:

**DEMO**

- 1 Press the preprogrammed **Emergency** button.

The display shows **EMERGENCY** and the current zone or channel.

You hear a short, medium-pitched tone and the LED momentarily blinks red.

**OR**

You hear the radio sounds a short low-pitched tone to indicate the selected channel does not support emergency and rejects to launch emergency mode.

- 2 The radio enters the Emergency Call state when:

You receive the dispatcher's acknowledgment.

The display shows **ACK RCVD**.

**OR**


You receive no acknowledgement.

The display shows **NO ACK**.

**OR**

You press the **PTT** button while in the Emergency Alarm mode.

- 3 Press and hold the **PTT** button.  
Speak clearly into the microphone.
- 4 Release the **PTT** button to end the transmission and wait for a response from the dispatcher.
- 5 Press and hold the preprogrammed **Emergency** button for about a second to exit the Emergency Call mode.



## ❑ Emergency Operation

### *Sending a Silent Emergency Alarm*

This feature allows you to send an Emergency Alarm to another radio without any audio or visual indicators.

#### Procedure:

A green rectangular button with the word "DEMO" in white capital letters.

- 1 Press the preprogrammed **Emergency** button.  
The display shows no changes, the LED does not light up, and you hear no tones.

#### **The silent emergency state continues until you:**

Press and hold the preprogrammed **Emergency** button for about a second to exit the Silent Emergency Alarm mode.

#### **OR**

Press and release the **PTT** button to exit the Silent Emergency Alarm mode and enter regular dispatch or Emergency Call mode.

#### **Note:**

#### **For ALL Emergency signals, when changing channels:**

- If the new channel is also preprogrammed for Emergency, you can change channels while in Emergency operation. The emergency alarm or call continues on the new channel.
- If the new channel is NOT preprogrammed for Emergency, the display shows **NO EMERG**, and you hear an invalid tone until you exit the Emergency state or change to a channel preprogrammed for Emergency.




## ❑ Emergency Operation

### *Using the Emergency Keep-Alive Feature*

This feature, when enabled, prevents the radio from being turned off via the **On/Off Control Knob** when the radio is in the Emergency state.

**Note:** The radio only exits the Emergency state using one of the ways mentioned in the previous sections.



## ❏ Man Down

Man Down condition is determined based upon the radio tilt angle or a combination of radio tilt angle and the lack of radio motion.

Man Down feature is an alternate way to activate the Emergency feature if Emergency has been programmed in your radio.

Your radio automatically activates Emergency Alarm or Call when the radio achieves or passes a tilt angle threshold or a combination of the angle threshold and radio motion below the motion sensitivity level, depending upon how the radio is programmed. The radio must stay in this condition for a preprogrammed amount of time before the Emergency Alarm or Call is activated.

**Note:** It is recommended that an **Emergency** button is preprogrammed in order to allow the user to exit the emergency condition.

The Man Down feature provides a **Clear** function to the user. After a Man Down condition has been detected, the user can press a preprogrammed **Clear** button or preprogrammed **Menu Select** button to cancel the Man Down condition. The radio remains in the Man Down state without triggering an emergency condition until the radio is moved out of the Man Down state, at which point Man Down functionality resumes.

The Man Down feature has three phases:

- i The radio senses the Man Down condition and **Pre-Alert Timer** is initiated.
- ii Man Down condition continues for the time duration defined in the **Pre-Alert Timer** field. At the end of this time, the radio alerts the user on the Man Down status with an audible alert tone and **Man Down** text on the screen. The Post-Alert Timer also initiates at this point.
- iii Man Down condition continues for the time duration defined in the **Post-Alert Timer** field. Once the timer expires, the Emergency alarm is transmitted. The Man Down Clear function is used in this phase to cancel the Man Down condition.

The following scenarios affect the timers:

- Pressing the **PTT** button suspends the Man Down timers; releasing the **PTT** button reinitiates the **Pre-Alert Timer**.
- Pressing other buttons on the radio does not impact these timers.
- Repositioning the radio exits the Man Down feature, which stops and resets the timers.
- Pressing a preprogrammed **Clear** button or pressing a **Menu Select** button preprogrammed for **Clear** stops and resets the timers. The timers do not restart until the radio is repositioned.

**Note:** Emergency must be set up for this feature to operate.

If the radio is preprogrammed to horizontal only, it must be worn in a vertical position otherwise the Man Down alert may be inadvertently triggered.

When the radio is programmed with Man Down feature, special care is required when charging the radio with a wall mounted charger.

### **Pre-Alert Timer**

This timer sets the amount of time that a Man Down condition must be present before the radio-user is warned of the Man Down condition.

When the radio detects that it has returned to the vertical position or when the radio detects motion, the Pre-Alert timer stops and is reset.

The Pre-Alert timer reinitiates when the radio detects it is in the horizontal position or motionless again.

### **Post-Alert Timer**

This timer sets the amount of time the radio needs to remain in the Man Down condition before the Emergency alarm is transmitted. When the Post-Alert Timer is initiated, the radio alerts the user with an audible tone and displays the “Man-Down” text.

### **Alerting User When Man Down Feature is Triggered**

The Man Down alert tone volume is directly related to the radio's volume. Ensure that the radio's volume is loud enough so that the user does not miss the Post-Alert tone.

**Note:** If the radio is programmed with Silent Emergency, the radio inhibits the alert tone and visual alert associated with the emergency feature.

**Note:** If the radio is programmed in Surveillance Mode, the radio inhibits all tones and lights on the radio including the Man Down tones.

### **Triggering Emergency**

When the user does not clear the Man Down condition and the Post-Alert Timer comes to an end, Emergency Alarm or call is triggered. The radio sends emergency message to units within the same Talkgroup. The radio also sends ID number and GPS coordinates to dispatcher if these features are enabled. User can exit Emergency following the Emergency procedure.

**Note:** At this point the Man Down features is complete. Use normal Emergency procedures to cancel Emergency transmissions.

### Exiting Man Down Feature

If you are not in a real Man Down situation, you should exit the Man Down feature and prevent emergency from going off with the following operation.

#### **Procedure:**

Repositioning the radio or shaking the radio (when motion sensitivity is enabled).

**OR**

Press the preprogrammed **Man Down Clear** button to exit.

**OR**

Press the **Menu Select** button below **Clr** to exit.

### Re-Initiating Man Down

After exiting the Emergency Operation when the radio is still in Man Down condition (tilted achieving threshold angle or motionless), user must first exit Man Down condition to then reinitiate the Man Down feature.

#### **Procedure:**

Return the radio to the vertical position.

**OR**

Shake the radio (when motion sensitivity is enabled).

### Testing the Man Down Feature

**Note:** Enable the Emergency feature with Silent Alarm disabled, but not in Surveillance Mode before running this test on the radio.

#### **Procedure:**

When Man Down is enabled on the radio:

- 1 Turn the radio on and place in the vertical position, for at least 5 seconds.
- 2 Lay the radio down in the horizontal position.
- 3 Wait for alert tone.

The radio alerts with audible tone and displays **MAN-DOWN**.

**OR**

If no tone is heard, make sure that the Man Down feature is enabled on your radio.

If Man Down feature was not enabled, please enable it and go through steps 1,2 and 3 again.

**OR**

If the Man Down feature is enabled and no tone is heard, send the radio to a qualified technician.

### Handling Man Down Functional Error Messages

#### **Procedure:**

- 1 If your radio display shows one of the following error messages: **HW BOARD ABSENT, MAN-DOWN HW ERROR** or **HW BOARD MISMATCH**.  
Send the radio to the qualified technician to fix this error.

## Man Down Functional Test

**Note:** Throughout the procedure, the radio should pivot on the dot in the bottom left hand corner of this page.

### Procedure:

**Step 1** Place the radio beside the vertical line on this leaflet with the speaker facing right and antenna against/beside this leaflet. Turn the radio on and wait for at least 5 seconds to ensure the Man Down mode is enabled.

**Step 2** Lay the radio down horizontally on its speaker side with the antenna pointing to the right.

**Step 3** When you hear an audible alert tone, rotate the radio up until the tone stops sounding.

**OR**

If you do not hear an audible alert tone, ensure that Step 1 have been properly performed.

Repeat the steps from Step 1.



If this situation persists after repetitive tests, return the radio to the qualified technician for servicing.

**Note:** You must rotate the radio fast enough to disable the Man Down mode before the radio transmits the emergency alarm.

**Step 4** Verify that the radio angle when the audible alert tone stops sounding is within the limits (shaded grey) in this diagram.

**Note:** If the radio alert tone stops sounding outside the limits, return the radio to qualified technician for servicing.

Step 1 – Place radio in vertical position.



Step 2 – Place radio in horizontal position.

## ❑ Secure Operations

### *Selecting Secure/Clear Transmissions*

Secure radio operation provides the highest commercially available level of voice security on both trunked and conventional channels.

Unlike other forms of security, Motorola digital encryption provides signaling that makes it virtually impossible for others to decode any part of an encrypted message.

#### **Procedure:**

- 1 Press the preprogrammed **Secure/Clear** button to the secure or clear position.

**Note:** If the selected channel is preprogrammed for clear-only operation – when you press the **PTT** button, you hear an invalid mode tone and the display shows **CLR TX**. The radio will not transmit until you set the **Secure/ Clear** button to the clear position.

**Note:** If the selected channel is preprogrammed for secure only operation – when you press the **PTT** button, you hear an invalid mode tone and the display shows **SEC TX**. The radio will not transmit until you set the **Secure/ Clear** button to the secure position.



## ❑ Secure Operations

### *Loading an Encryption Key*

**Note:** Refer to the key-variable loader (KVL) manual for equipment connections and setup.

#### Procedure:

- 1 Attach the KVL to your radio.  
The display shows **KEYLOAD**, and all other radio functions, except for power down, backlight, and volume, are locked out.
- 2 Select the required keys and press the **Menu Select** button directly below **LOAD** on the KVL.  
This loads the encryption keys into your radio.

When the key has been loaded successfully, you hear a short tone for single-key radios.

**OR**

When the key has been loaded successfully, you hear an alternating tone for multikey radios.



## ❑ Secure Operations

### *Using the Multikey Feature*

This feature allows the radio to be equipped with different encryption keys and supports the DES-OFB algorithm.

There are two types:

- **Conventional Multikey** – The encryption keys can be tied (strapped), on a one-per-channel basis, through Customer Programming Software. In addition, you can have operator-selectable keys, operator-selectable keysets, and operator-selectable key erasure. If talk groups are enabled in conventional, then the encryption keys are strapped to the talk groups.
- **Trunked Multikey** – If you use your radio for both conventional and trunked applications, you have to strap your encryption keys for trunking on a per-talkgroup or announcement-group basis. In addition, you may strap a different key to other features, such as dynamic regrouping, fail-soft, or emergency talkgroup. You can have operator-selectable key erasure.



## ❑ Secure Operations

### *Erasing the Selected Encryption Keys*

This feature allows you to erase all or selected encryption keys.

#### Procedure:

**DEMO**

- 1 Press and hold the **Top Side (Select)** button.
- 2 While holding **Top Side (Select)** button down, press the **Top (Orange)** button.  
The display shows **PLS WAIT**.  
When all the encryption keys have been erased, the display shows **ALL ERASED**.

**Note:** **DO NOT** press the **Top (Orange)** button before pressing the **Top Side (Select)** button, unless you are in an emergency situation as this sends an emergency alarm.



## ❑ Secure Operations

### *Requesting an Over-the-Air Rekey (ASTRO Only)*

This feature, also known as **OTAR**, allows the dispatcher to reprogram the encryption keys in the radio remotely. The dispatcher performs the rekey operation upon receiving a rekey request from the user.

#### Procedure:

- 1 Press and hold the preprogrammed Rekey Request button to send the rekey request.  
If the rekey operation fails, a bad-key tone sounds and the display shows **RKY FAIL**.

**Note:** The rekey operation failure indicates that your radio does not contain the Unique Shadow Key (USK). This key must be loaded into the radio with the key-variable loader (KVL) before the rekey request can be sent. Refer to your local key management supervisor for more information.



## ❑ Secure Operations

### *MDC Over-the-Air Rekeying (OTAR) Page*

This feature allows to view or define MDC Over-the-Air Rekeying (OTAR) features. It is applied only when operating in secure encrypted mode and only for conventional communications. In addition to Rekey Requests, OTAR transmissions include Delayed Acknowledgements, and Power up Acknowledgements.

Some of the options selected may also need to be set up at the Key Management Controller (KMC) site to work properly.

**Note:** This feature must be preprogrammed by a qualified radio technician. Check with your dealer or system administrator for more information.



## ❑ Secure Operations

### *Hear Clear*

There are two components of Hear Clear.

#### 1 **Companding:**

Reduces the channel noise, e.g. OTA transmission, that is predominantly present in UHF2 and 900 MHz channel with the following features.

- **Compressor** – reduces the background noise flow and the speech signal at transmitting radio.
- **Expander** – expands the speech while the noise flow remains the same at receiving radio.

#### 2 **Random FM Noise Canceller (Flutter Fighter):**

Reduces the unwanted effects of random FM noise pulses caused by channel fading under high Signal-to-Noise (S/N) conditions such as in a moving in a transportation.

The fading effects, heard as audio pops and clicks, are cancelled without affecting the desired audio signal.

The Random FM Noise Canceller operates only in receive mode.

**Note:** This feature must be preprogrammed by a qualified radio technician. Check with your dealer or system administrator for more information.



## ❑ Trunking System Controls

### *Using the Fail-soft System*

The fail-soft system ensures continuous radio communications during a trunked system failure.

If a trunking system fails completely, the radio goes into fail-soft operation and automatically switches to its fail-soft channel.

#### Procedure:

- 1 During fail-soft operation, your radio transmits and receives in conventional operation on a predetermined frequency.
- 2 You hear a medium-pitched tone every 10 seconds and the display shows **FAILSOFT**.

When the trunking system returns to normal operation, your radio automatically leaves fail-soft operation and returns to trunked operation.





## ❑ Trunking System Controls

### *Going Out of Range*

When your radio goes out of the range of the system, it can no longer lock onto a control channel.

#### Procedure:

**DEMO**

- 1 You hear a low-pitched tone.

#### **AND/OR**

The display shows the currently selected zone/channel combination and **OUT RNG**.

Your radio remains in this out-of-range condition until:  
It locks onto a control channel.

#### **OR**

It locks onto a fail-soft channel.

#### **OR**

It is turned off.





## ❑ Trunking System Controls

### *Using the Site Trunking Feature*

If the zone controller loses communication with any site, that site reverts to site trunking.

The display shows the currently selected zone/channel combination and **STE TRNK**.

**Note:** When this occurs, you can communicate only with other radios within your trunking site.



## ❑ Trunking System Controls

### *Locking and Unlocking a Site*

This feature allows your radio to lock onto a specific site and not roam among wide-area talkgroup sites. This feature should be used with caution, since it inhibits roaming to another site in a wide-area system.

#### Procedure:

- 1 Use the preprogrammed **Site Lock/Unlock** button to toggle the lock state between locked and unlocked.

The radio saves the new site lock state and returns to the Home screen.



## ❑ Trunking System Controls

### *Viewing and Changing a Site*

This feature allows you to view the name of the current site or forces your radio to change to a new one.

#### Viewing the Current Site

##### Procedure:

[DEMO](#)

- 1 Press the preprogrammed **Site Displ/Srch** button. The display momentarily shows the name of the current site and its corresponding received signal strength indicator (RSSI).

#### Changing the Current Site

##### Procedure:

[DEMO](#)

- 1 Press and hold down the preprogrammed **Site Displ/Srch** button. You hear a tone and the display momentarily shows **SCANNING**. When the radio finds a new site, it returns to the Home screen.

## ❑ Mission Critical Wireless - Bluetooth® -

### *Turning the Bluetooth On/Off*

**Note:** The use of this feature requires the "Full Feature" expansion board together with the Bluetooth Software.

This feature allows your radio to extend its functionality by connecting to external proprietary Motorola Accessories.

The default setting for Bluetooth-enabled radio is Bluetooth ON.


**Note:** Your radio must be preprogrammed to allow you to use this feature.

#### Procedure:

- 1 Press the preprogrammed button to turn the Bluetooth on or off.

##### Turn Bluetooth ON:

You hear a short, medium-pitched tone.

The display shows momentary **BT ON**, and  appears to indicate Bluetooth is on.

##### OR

The display shows **BT ON FL** to indicate Bluetooth has failed to launch.

##### Turn Bluetooth OFF:

You hear a short, medium-pitched tone.

The display shows momentary **BT OFF**, and  disappears.

## ❑ Mission Critical Wireless - Bluetooth® - *Re-Pair Timer*

There are two options for configuring the radio's Bluetooth pairing type. The type defines the duration the radio and the accessory retain the pairing information.

- **Immediate** — (For headset and PTT only.) When the radio and/or device is turned off after pairing, the keys are lost. Due to this, when your radio and your device are turned back on, they are unable to re-connect. The user must re-pair the devices to re-establish a new set of pairing keys.
- **Infinite** — (For headset, PTT and data devices.) When the radio and/or device are turned off after pairing, keys are NOT lost. When the radio and the device are turned back on, they can resume the Bluetooth connection without user intervention.

Re-Pair Timer Options	Re-Pair Timer Scenarios
Immediate (for headset and PTT only)	<ul style="list-style-type: none"> <li>• When the radio is powered OFF, pairing key is lost immediately, and accessory attempts to pair again. If pairing is unsuccessful within the Drop Timer value, the accessory automatically powers OFF.</li> <li>• When the accessory is powered OFF, all keys are lost immediately, and the user must re-pair the devices.</li> <li>• When the devices lose Bluetooth connection, the devices will attempt to reestablish Bluetooth Connection within the Drop Timer value.</li> </ul>
Infinite (for headset, PTT and data devices)	<ul style="list-style-type: none"> <li>• When the radio is powered OFF, the accessory attempts to re-establish the Bluetooth Connection for a period of time depending upon the Drop Timer value. If the devices fails to reconnect within the period, the accessory then powers OFF.</li> </ul>

## ❑ Mission Critical Wireless - Bluetooth® - *Bluetooth Drop Timer*

The Bluetooth Drop Timer has two different settings and functions, depending upon the selection of the Re-Pair Timer.

Re-Pair Timer Options	Re-Pair Timer Scenarios
Immediate (for headset and PTT only)	0 – 15 minutes programmable buffer time to re-establish the Bluetooth Connection when the Bluetooth signal is out of range. If either device powers OFF, the pairing keys are immediately cleared from both devices and the devices must re-pair.
Infinite (for headset, PTT and data devices)	This Timer only applies to the accessory. The programmable timer choices are: 0 – 15 minutes, 2 hours, 4 hours or 8 hours. This is a "stay alive" time that the accessory will remain ON without the devices reconnecting before powering off. The radio will remain ON until the user powers the Radio OFF. The radio and accessory will remain paired indefinitely. Once the devices re-connect, the timer is reset.



## ❑ Mission Critical Wireless - Bluetooth® - *Pairing Bluetooth Device with the Radio*

The range of Bluetooth operation is 10 meters line-of-sight communication. This is an unobstructed path between the location of the signal transmitter (your radio) and the location of the receiver (your device or accessory).

Obstacles that can cause an obstruction in the line-of-sight include trees, buildings, mountains, cars and etc.

It is NOT recommended that you leave your radio behind and expect your accessory to work with a high degree of reliability when they are separated.

At the fringe areas of reception, both voice and tone quality will start to sound "garbled" or "broken". To correct this problem, simply position the accessory and radio closer to each other (within the 10 meter defined range) to re-establish clear audio reception.

### Procedure:

**Note:** Bluetooth tones, Bluetooth menu and Preprogrammed buttons must be preprogrammed by a qualified radio technician. Check with your dealer or system administrator for more information.

With your radio's Bluetooth feature ON, and the Bluetooth tones enabled:



- 1 Turn the accessory on, then place it close to your radio aligning the blue dot-pairing indicator on the radio and the accessory.

If the pairing process is successful, you hear an incremental-pitched tone to indicate paired.

#### OR

If the pairing process fails, you hear a short, low-pitched tone.

The display shows Bluetooth alternating with pairing failed.

- 2 The radio continues to connect to the device.  
If the connecting process is successful, you hear an incremental-pitched tone.  
The display shows <Device Type> **CONNECTED**.  
The Bluetooth icon turns from  to .

**OR**

If the device already has pairing records and the connecting process fails, you hear a short, low-pitched tone.

The display shows **<Device Type> CON FAIL.**

Re-initiate the pairing process.

**OR**

If the connecting process is immediately following the pairing process and the connecting process fails to complete within the 6 seconds, you hear a decremented pitched tone to indicate unpaired.


The display shows **<Device Type> UNPAIRED.**

Re-initiate the pairing process.







## ❑ Mission Critical Wireless - Bluetooth® - *Indicating Bluetooth Connection is Lost*

The radio shows  when the devices have a Bluetooth connection. Below is the scenario and radio indications when the connection is interrupted.



### Procedure:

- 1 The  starts blinking for up to 10 seconds. You hear a decremented-pitched tone and the display shows **<Device Type>** alternating with **CON LOST**.

If the Bluetooth device fails to re-connect within 10 seconds, the display shows momentary **<Device Type> CONNECTED**.

 stops blinking.

### OR

If the Bluetooth device fails to re-connect within 10 seconds, the blinking  is replaced by a persistent .



## ❑ Mission Critical Wireless - Bluetooth® -

*Turning On/Off the Bluetooth Audio*

### Procedure:

- 1 Press the preprogrammed button to route the audio routing from the radio to the headset  
OR to route the audio routing from the headset to the radio.

The display shows momentary **HDSET ON**  
OR **Speaker on**.

### Adjusting the Volume of the Radio from Bluetooth Audio Device

Adjust volume up/down on the Bluetooth audio device.  
You hear a short, medium-pitched tone.  
The radio display shows volume bars and **VOL XX**.

## ❑ Mission Critical Wireless - Bluetooth® - *Clearing All Pairing Information*

### Procedure:

- 1 Long press the preprogrammed Bluetooth On/Off button.  
You hear a short, medium-pitched tone.

The display shows **PLS WAIT** to indicate clearing is in progress.

The display shows **ALL CLR** to indicate clearing is successful.

#### OR

You hear the radio sounds a short, low-pitched tone.

The display shows **CLR FAIL** to indicate clearing has failed.

**Note:** If Re-Pair Timer is set to infinite and you clear keys on the radio, you must clear keys on all previously paired devices as well. (Please see your accessories manual for further details.)



<a href="#"><u>Using the Flip Display .....</u></a>	93
<a href="#"><u>Selecting a Basic Zone Bank .....</u></a>	94
<a href="#"><u>Selecting an Enhanced Zone Bank .....</u></a>	95
<a href="#"><u>Selecting the Power Level .....</u></a>	96
<a href="#"><u>Controlling the Display Backlight .....</u></a>	97
<a href="#"><u>Locking and Unlocking the Controls .....</u></a>	98
<a href="#"><u>Turning Voice Mute On or Off .....</u></a>	99
<a href="#"><u>Using the Time-Out Timer .....</u></a>	100
<a href="#"><u>Using the Conventional Squelch Operation Features .....</u></a>	101
<a href="#"><u>Using the PL Defeat Feature .....</u></a>	102
<a href="#"><u>Using the Digital PTT ID Feature .....</u></a>	103
<a href="#"><u>Using the Smart PTT Feature (Conventional Only) .....</u></a>	104
<a href="#"><u>Voice Announcement .....</u></a>	105


## ❑ Using the Flip Display

This feature allows you to flip the content of the top display upside down. It is particularly useful when you would like to read the top display while the radio is still in the carry holder attached to your belt.

### Procedure:

**DEMO**

- 1 Press and hold the preprogrammed **Light/Flip** button to flip the display.




## ❑ Selecting a Basic Zone Bank

This feature allows twice as many zones to be accessed from a switch, doubling the amount of switch positions.

**Note:** The Basic Zone Select feature must to be preprogrammed to the **3-position A-B-C switch**, while the Basic Zone Bank feature must be preprogrammed to any side button or **Top (Orange)** button before you can use this feature.

### Procedure:

- 1 Use the preprogrammed **Basic Zone Bank** button to toggle the position between Bank 1 and Bank 2.
- 2 The top display shows the status icons (**A, B, C, D, E or F**) or the zone name based on the bank and switch position selected.



## ❑ Selecting an Enhanced Zone Bank

This feature is created in order to allow users to communicate in more zones. An **Enhanced Zone Bank (EZB)** consists of three zones. This also means each icon **A, B, C, ...** or **Y** consist of three zones. You can use the preprogrammed 3-position A-B-C switch to select the first, second or third zone in an EZB.

This feature allows user to navigate from up to 75 zones in 25 EZBs.

Note: The Zone Select feature must to be preprogrammed to the 3-position A-B-C switch, while the Enhanced Zone Bank feature must be preprogrammed to any side button or **Top (Orange)** button before you can use this feature.

### Procedure:

- 1 Press the preprogrammed **EZB Up** or **EZB Down** button to scroll the EZB up or down.  
**OR**  
Press and hold the preprogrammed **EZB Up** or **EZB Down** button to fast scroll the EZB up or down.
- 2 Turn the **3-Position A/B/C Switch** to select the first, second or third zone in the selected EZB.

## ❑ Selecting the Power Level

This feature enables you to reduce the transmit power level for specific case that require a lower power level. You can select the power level at which your radio transmits. The radio always turns on to the default setting.

**Note:** Please refer to your agent or qualified radio technician to enable or disable this feature.

These reduced transmit power level settings do not affect your radio's receiving performance, nor diminish the overall quality of the radio's audio and data functionality given with the following conditions.

### Settings:

- Select **Low** for a shorter transmitting distance and to conserve power.
- Select **High** for a longer transmitting distance.

### Procedure:

- 1 Use the preprogrammed **Transmit Power Level** button to toggle the power level between low and high power. The display shows **LOW PWR** and the low power icon.  
**OR**  
The display shows **HIGH PWR** and the high power icon.



## ❏ Controlling the Display Backlight

You can enable or disable the radio's display backlight as needed, if poor light conditions make the display or keypad difficult to read.

Depending on how your radio is preprogrammed, you can also maintain a minimum backlight level on the radio's front display.

**Note:** The backlight setting also affects the **Menu Select** buttons, the **Menu Navigation** buttons and the keypad backlighting accordingly.

### Procedure:

- 1 Press the preprogrammed **Light/Flip** button to toggle the backlight on or off.

**OR**

Press any key of the keypad, the **Menu Select** or **Menu Navigation** buttons, or any programmable radio controls or buttons to turn the backlight on.

**Note:** The backlight remains on for a preprogrammed time before it automatically turns off completely or returns to the minimum backlight level.

## ❑ Locking and Unlocking the Controls

You can lock your radio's programmable buttons, switches and rotary knobs to avoid inadvertent entry.

Check with your dealer or qualified technician for best selection to suite your usage.

### Procedure:

- 1 Toggle the preprogrammed **Keypad Lock** button to on. The display shows **CTRL LCK..**
- 2 Toggle again to unlock.



## ❑ Turning Voice Mute On or Off

You can enable and disable voice transmission, if needed.


### Procedure:

- 1 Press the preprogrammed **Voice Mute** button to turn the feature off or on.

The display momentarily shows **VMUT OFF**, and you hear a short tone, indicating that the feature is disabled.

**OR**

The display momentarily shows **VMUT ON**, and you hear a short tone, indicating that the feature is enabled.



## ❑ Using the Time-Out Timer

This feature turns off your radio's transmitter. You cannot transmit longer than the preset timer setting.

If you attempt to do so, the radio automatically stops your transmission, and you hear a talk-prohibit tone.

The timer is defaulted at 60 seconds, but it can be preprogrammed from 3 to 120 seconds, in 15-second intervals, or it can be disabled entirely for each radio mode, by a qualified radio technician.

**Note:** You will hear a brief, low-pitched, warning tone four seconds before the transmission times out.

### Procedure:

- 1 Hold down the **PTT** button longer than the preprogrammed time.  
You hear a short, low-pitched warning tone, the transmission is cut-off, and the LED goes out until you release the **PTT** button.
- 2 Release the **PTT** button.  
The timer resets.

- 3 Press the **PTT** button to re-transmit.  
The time-out timer restarts and the LED lights up solid red.

❑ Using the Conventional Squelch Operation Features

This feature filters out unwanted calls with low signal strength or channels that have a higher than normal background noise.

Analog Options

Tone Private Line (PL), Digital Private-Line (DPL), and carrier squelch can be available (preprogrammed) per channel.

Mode	Result
Carrier squelch (C)	You hear all traffic on a channel.
PL or DPL	The radio responds only to your messages.

Digital Options

One or more of the following options may be preprogrammed in your radio.

Check with your dealer or system administrator for more information.

Option	Result
Digital Carrier-Operated Squelch (COS)	You hear any digital traffic.
Normal Squelch	You hear any digital traffic having the correct network access code.
Selective Switch	You hear any digital traffic having the correct network access code and correct talkgroup.

## ❑ Using the PL Defeat Feature

This feature allows you to override any coded squelch (DPL or PL) that might be preprogrammed to a channel.

The radio will also unmute to any digital activity on a digital channel.

### Procedure:

- 1 Place the preprogrammed **PL Defeat** button in the PL Defeat position.

You hear any activity on the channel.

**OR**

The radio is muted if no activity is present.


**Note:** When this feature is active, the Carrier Squelch status indicator is displayed.



## ❑ Using the Digital PTT ID Feature

This feature allows you to see the radio ID (number) of the radio from whom you are currently receiving a transmission. This ID, consisting up to a maximum of eight characters, can be viewed by both the receiving radio and the dispatcher.

Your radio's ID number is also automatically sent every time the **PTT** button is pressed. This is a per-channel feature. For digital voice transmissions, your radio's ID is sent continuously during the voice message.



❑ Using the Smart PTT Feature (Conventional Only)

Smart **PTT** is a per-personality, programmable feature used in conventional radio systems to keep radio users from talking over other radio conversations.

When smart **PTT** is enabled in your radio, you cannot transmit on an active channel.

If you try to transmit on an active smart-**PTT** channel, you hear an alert tone, and the transmission is inhibited. The LED lights up solid yellow to indicate that the channel is busy.

Three variations of smart **PTT** are available:

Mode	Description
Transmit Inhibit on Busy Channel with Carrier	You cannot transmit if any traffic is detected on the channel.
Transmit Inhibit on Busy Channel with Wrong Squelch Code	You cannot transmit on an active channel with a squelch code or (if secure-equipped) encryption key other than your own. If the PL code is the same as yours, the transmission is not prevented.
Quick-Key Override	This feature can work in conjunction with either of the two above variations. You can override the transmit-inhibit state by quick-keying the radio. In other words, two <b>PTT</b> button presses within the preprogrammed time limit.



## ❑ Voice Announcement

This feature enables the radio to audibly indicate the current feature mode, Zone or Channel the user has just assigned.

This audio indicator can be customized per customer requirements.

This is typically useful when the user is in a difficult condition to read the content shown on the display.

Each voice announcement is within a limit of three seconds maximum. The sum total duration for all voice announcements in a radio shall be no more than 1000 seconds.

**Note:** This feature must be preprogrammed by a qualified radio technician.

The features which Voice Announcement supports are:

- Zone
- Channel
- Scan
- PL Disabled
- Talkaround/Direct
- Tx Inhibit

**Note:** Voice announcements support certain number of zone-channel, but not all.

Seek advice from your dealer or qualified technician for the best selection of this feature.

The two options of priority for the Voice Announcement available are:

- **High** – enables the voice of the feature to announce even when the radio is receiving calls.
- **Low** – disables the voice of the feature from announcing when the radio is receiving calls.

### Procedure:

You hear a voice announcement when the features below are preprogrammed in the radio.

- The radio powers up. The radio announces the current zone and channel it is transmitting.
- Press the preprogrammed voice announcement button (which specifically programmed to playback the current zone and channel). The radio announces the current zone and channel it is transmitting.

**Note:** Pressing this preprogrammed playback button will always enable the voice feature to announce in High priority.  
All the three programmable buttons at the side of the radio support this feature.

- Change to a new zone. The radio announces the current zone and channel it is transmitting.
- Change to a new channel remaining within the current zone.  
The radio announces the current channel.
- Press either the preprogrammed button or switch of the radio to launch or terminate Scan, PL Disabled, Talkaround/Direct or Transmit Inhibit.  
The radio announces the corresponding feature activation.

